

Your Phone

Cisco IP Phone 7841 shown.

- 1 Incoming call or voicemail indicator
- 2 Line and feature buttons
- 3 Softkeys
- 4 Navigation
- (5) Hold, Transfer, and Conference
- (6) Speakerphone, Headset, and Mute
- Voicemail, Applications, and Directory
- 8 Volume

Line and Feature Buttons

Use line and feature buttons to view calls on a line, or access features such as Speed Dial.

Buttons illuminate to indicate status:

- Green, steady: Active call
- · Green, flashing: Held call
- Amber, steady: Private line in use
- · Amber, flashing: Incoming call
- · Red, steady: Remote line in use
- · Red, flashing: Remote line on hold

Place a Call

Enter a number and pick up the handset.

Answer a Call

Press the flashing amber line button.

Put a Call on Hold

- 1. Press Hold
- 2. To resume a call from hold, press Hold again.

View Your Recent Calls

- 1. Press Applications
- 2. Scroll and select Recents.
- 3. Select a line to view.

Add Another Person to a Call (7811)

- 1. From an active call, press Conference
- 2. Press Calls, select a held call, and press Yes.

Add Another Person to a Call (7821, 7841, 7861)

- 1. From an active call, press Conference
- 2. Select a held call and press Yes.

Cisco IP Phone 7800 Series

Quick Start Guide

Transfer a Call to Another Person

- 1. From a call that is not on hold, press **Transfer**
- 2. Enter the other person's phone number.
- 3. Press Transfer again.

Make a Call with a Headset

- 1. Plug in a headset.
- 2. Enter a number using the keypad.
- 3. Press **Headset**

Make a Call with the Speakerphone

- 1. Enter a number using the keypad.
- 2. Press **Speakerphone** . .

Mute Your Audio

- 1. Press Mute .
- 2. Press Mute again to turn mute off.

Listen to Voice Messages

Press **Messages** and follow the voice prompts. To check messages for a specific line, press the line button first.

Forward All Calls

- 1. Select a line and press Fwd all.
- 2. Dial the number that you want to forward to, or press **Voicemail**.
- 3. When you return, press Forward off.

Adjust the Volume in a Call

Press Volume up or down to adjust the handset, headset, or speakerphone volume when the phone is in use.

Adjust the Ringtone Volume

Press Volume up or down to adjust the ringer volume when the phone is not in use.

Change Ringtone

- 1. Press Applications
- 2. Select Preferences > Ringtone.
- 3. Select a line.
- 4. Scroll through the list of ringtones and press **Play** to hear a sample.
- 5. Press Set and Apply to save a selection.

Adjust the Screen Contrast

- 1. Press Applications .
- Select Preferences > Contrast.
- Press up to increase, or down to decrease, the contrast.
- 4. Press Save.

Adjust the Screen Backlight

- 1. Press Applications
- 2. Select Preferences > Backlight.
- 3. Press On to set the backlight on or press Off to set backlight off.